


ASAE EP463.2 NOV2009
Design, Construction, and Maintenance of Subsurface
Drains in Arid and Semiarid Areas



American Society of
Agricultural and Biological Engineers



S
T
A
N
D
A
R
D

ASABE is a professional and technical organization, of members worldwide, who are dedicated to advancement of engineering applicable to agricultural, food, and biological systems. ASABE Standards are consensus documents developed and adopted by the American Society of Agricultural and Biological Engineers to meet standardization needs within the scope of the Society; principally agricultural field equipment, farmstead equipment, structures, soil and water resource management, turf and landscape equipment, forest engineering, food and process engineering, electric power applications, plant and animal environment, and waste management.

NOTE: ASABE Standards, Engineering Practices, and Data are informational and advisory only. Their use by anyone engaged in industry or trade is entirely voluntary. The ASABE assumes no responsibility for results attributable to the application of ASABE Standards, Engineering Practices, and Data. Conformity does not ensure compliance with applicable ordinances, laws and regulations. Prospective users are responsible for protecting themselves against liability for infringement of patents.

ASABE Standards, Engineering Practices, and Data initially approved prior to the society name change in July of 2005 are designated as 'ASAE', regardless of the revision approval date. Newly developed Standards, Engineering Practices and Data approved after July of 2005 are designated as 'ASABE'.

Standards designated as 'ANSI' are American National Standards as are all ISO adoptions published by ASABE. Adoption as an American National Standard requires verification by ANSI that the requirements for due process, consensus, and other criteria for approval have been met by ASABE.

Consensus is established when, in the judgment of the ANSI Board of Standards Review, substantial agreement has been reached by directly and materially affected interests. Substantial agreement means much more than a simple majority, but not necessarily unanimity. Consensus requires that all views and objections be considered, and that a concerted effort be made toward their resolution.

CAUTION NOTICE: ASABE and ANSI standards may be revised or withdrawn at any time. Additionally, procedures of ASABE require that action be taken periodically to reaffirm, revise, or withdraw each standard.

Copyright American Society of Agricultural and Biological Engineers. All rights reserved.

ASABE, 2950 Niles Road, St. Joseph, MI 49085-9659, USA ph. 269-429-0300, fax 269-429-3852, hq@asabe.org




Figure 1 - Curve showing general relationship between specific yield and hydraulic conductivity

a depth by the shortest time interval between deep percolation events, usually the time between irrigations at the peak of the season.

5.3.7 Drain spacing equations. Numerous methods for calculating drain spacing exist, but the Donnan steady-state equation and the US Bureau of Reclamation transient flow method are in common use.

5.3.7.1 Steady-state method. Donnan's steady-state equation can be expressed as:

$$L^2 = \frac{4K(b^2 - a^2)}{Q_d}$$

where

- L is drain spacing, m (ft);
- K is hydraulic conductivity, m/day (ft/day);
- a is distance from drain depth to barrier layer, m (ft);
- b is distance from maximum allowable water table height to the barrier layer;
- Q_d is recharge rate, m/day (ft/day) (see 5.3.6).

When the drain is to be placed on or near the barrier layer, it has been found through field experience by the US Bureau of Reclamation that drain spacing can be calculated by the following equation:

$$L^2 = \frac{8Kb^2}{Q_d}$$

Example:

Steady-state with drain above the barrier layer:

- L is drain spacing, m (ft);
- K is 3.05 m/day (10 ft/day);
- a is 6.71 m (22 ft);
- b is 7.92 m (26 ft);

deep percolation/irrigation is 25.4 mm (1 in.);
time between irrigations at peak of season is 14 days.

$$Q_d = \frac{25.4 \text{ mm}}{14 \text{ days (1000 mm/m)}} = 0.00181 \text{ m/day}$$

$$L_2 = \frac{4(3.05)(7.92^2 - 6.71^2)}{14 \text{ days (1000 mm/m)}}$$

$$L = 345 \text{ m}$$

$$Q_d = \frac{1 \text{ in.}}{14 \text{ days (12 in./ft)}} = 0.00595 \text{ ft/day}$$

$$L_2 = \frac{4(10)(26^2 - 22^2)}{0.00595}$$

$$L = 1,136 \text{ ft}$$

5.3.7.2 Transient flow method. The US Bureau of Reclamation's transient flow method for determining drain spacing takes into account the transient nature of ground-water recharge and discharge. This method simulates actual fluctuations of the water table to drain spacings that meet the requirement of keeping the water table below a specified depth. Figure 2 shows the dimensionless parameters Y/Y_0 vs. KD/SL^2 and Z/H vs. KH/SL^2 based on the transient flow theory. This figure shows the relationship for the water height at the midpoint between drains for cases in which drains are located above a barrier layer or on a barrier layer. Figure 2 can be used to find the proper drain spacing for dynamic equilibrium of the water table. However, water table elevations should be computed for an entire year to account for water removal by the drains during non-irrigated periods. Table 2 shows an example of